aiwa

aiwa SERVICE

# SX-FZR700
# SX-AZR800



SX-FZR700



SX-AZR800

SPEAKER

• TYPE: English

SERVICE MANUAL

S/M Code No. 09-974-199-5FE

# SX-FZR700 <YBNL, YJBNL, YJ7BNL, YLBNL>
# SPEAKER EXPLODED VIEW 1 / 1

Insert a flat-bladed screwdriver into the position indicated by the arrows and remove the panel.
Remove the screws of each speaker unit and then remove the speaker units.




## SPEAKER PARTS LIST 1 / 1

If can't understand for Description please kindly refer to " REFERENCE NAME LIST ".

| REF. NO. | PART NO. | KANRI NO. | DESCRIPTION |
|---|---|---|---|
| 1 | 87-MS5-017-010 | | GRILLE,FRAME ASSY R |
| 1 | 87-MS5-018-010 | | GRILLE,FRAME ASSY L |
| 2 | 87-MS5-001-010 | | PANEL,FR R |
| 2 | 87-MS5-002-010 | | PANEL,FR L |
| 3 | 87-MS5-015-010 | | PROTECTOR, R |
| 3 | 87-MS5-016-010 | | PROTECTOR, L |
| 4 | 87-MS5-007-010 | | PANEL,TW R |
| 4 | 87-MS5-008-010 | | PANEL,TW L |
| 5 | 87-MS5-601-010 | | SPKR,W 200 |
| 6 | 87-MS5-603-010 | | SPKR,MID 80 |
| 7 | 87-MS4-611-010 | | SPKR,CORD Y/B |
| 8 | 87-MS4-614-010 | | SPKR,CORD |
| 9 | 87-MS4-605-010 | | SPKR,SU 80 |

# SX-AZR800 <YBNL, YJBNL, YJ7BNL, YLBNL>
# SPEAKER EXPLODED VIEW 1 / 1

Insert a flat-bladed screwdriver into the position indicated by the arrows and remove the panel.
Remove the screws of each speaker unit and then remove the speaker units.




## SPEAKER PARTS LIST 1 / 1

If can't understand for Description please kindly refer to " REFERENCE NAME LIST ".

| REF. NO. | PART NO. | KANRI NO. | DESCRIPTION |
|---|---|---|---|
| 1 | 87-MS4-022-010 | | GRILLE,FRAME ASSY R |
| 1 | 87-MS4-023-010 | | GRILLE,FRAME ASSY L |
| 2 | 87-MS4-011-010 | | PROTECTOR,R |
| 2 | 87-MS4-012-010 | | PROTECTOR,L |
| 3 | 87-MS4-001-010 | | PANEL,FR R |
| 3 | 87-MS4-002-010 | | PANEL,FR L |
| 4 | 86-MS3-601-010 | | SPKR,W 200 |
| 5 | 87-MS4-603-010 | | SPKR,MID 80 |
| 6 | 87-MS4-605-010 | | SPKR,SU 80 |
| 7 | 87-NS4-605-010 | | SPKR,T 50 |
| 8 | 87-MS4-013-010 | | PROTECTOR,TOP |
| 9 | 87-MS4-007-010 | | CABI,TOP R |
| 9 | 87-MS4-008-010 | | CABI,TOP L |
| 10 | 87-MS4-611-010 | | SPKR,CORD Y/B |

# REFERENCE NAME LIST

## ELECTRICAL SECTION

| DESCRIPTION | REFERENCE NAME |
|---|---|
| ANT | ANTENNAS |
| C- | CHIP |
| C-CAP | CAP, CHIP |
| C-CAP TN | CAP, CHIP TANTALUM |
| C-COIL | COIL, CHIP |
| C-DI | DIODE, CHIP |
| C-DIODE | DIODE, CHIP |
| C-FET | FET, CHIP |
| C-FOTR | FILTER, CHIP |
| C-JACK | JACK, CHIP |
| C-LED | LED, CHIP |
| C-RES | RES, CHIP |
| C-SFR | SFR, CHIP |
| C-SLIDE SW | SLIDE SWITCH, CHIP |
| C-SW | SWITCH, CHIP |
| C-TR | TRANSISTOR, CHIP |
| C-VR | VOLUME, CHIP |
| C-ZENER | ZENER, CHIP |
| CAP, CER | CAP, CERA-SOL |
| CAP, E | CAP, ELECT |
| CAP, M/F | CAP, FILM |
| CAP, TC | CAP, CERA-SOL |
| CAP, TC-U | CAP, CERA-SOL SS |
| CAP, TN | CAP, TANTALUM |
| CERA FIL | FILTER, CERAMIC |
| CF | FILTER, CERAMIC |
| DL | DELAY LINE |
| E/CAP | CAP, ELECT |
| FILT | FILTER |
| FLTR | FILTER |
| FUSE RES | RES, FUSE |
| MOT | MOTOR |
| P-DIODE | PHOTO DIODE |
| P-SNSR | PHOTO SENSER |
| P-TR | PHOTO TRANSISTOR |
| POLY VARI | VARIABLE CAPACITOR |
| PPCAP | CAP, PP |
| PT | POWER TRANSFORMER |
| PTR, RES | PTR, MELF |
| RC | REMOTE CONTROLLER |
| RES NF | RES, NON-FLAMMABLE |
| RESO | RESONATOR |
| SHLD | SHIELD |
| SOL | SOLENOID |
| SPKR | SPEAKER |
| SW, LVR | SWITCH, LEVER |
| SW, RTRY | SWITCH, ROTARY |
| SW, SL | SWITCH, SLIDE |
| TC CAP | CAP, CERA-SOL |
| THMS | THERMISTOR |
| TR | TRANSISTOR |
| TRIMER | CAP, TRIMMER |
| TUN-CAP | VARIABLE CAPACITOR |
| VIB, CER | RESONATOR, CERAMIC |
| VIB, XTAL | RESONATOR, CRYSTAL |
| VR | VOLUME |
| ZENER | DIODE, ZENER |

## MECHANICAL SECTION

| DESCRIPTION | REFERENCE NAME |
|---|---|
| ADHESHIVE | SHEET ADHESHIVE |
| AZ | AZIMUTH |
| BAR-ANT | BAR-ANTENNA |
| BAT | BATTERY |
| BATT | BATTERY |
| BRG | BEARING |
| BTN | BUTTON |
| CAB | CABINET |
| CASS | CASSETTE |
| CHAS | CHASSIS |
| CLR | COLLAR |
| CONT | CONTROL |
| CRSR | CURSOR |
| CU | CUSHION |
| CUSH | CUSHION |
| DIR | DIRECTION |
| DUBB | DUBBING |
| FL | FRONT LOADING |
| FLY-WHL | FLYWHEEL |
| FR | FRONT |
| FUN | FUNCTION |
| G-CU | G-CUSHION |
| HDL | HANDOL |
| HIMERON | CLOTH |
| HINGE, BAT | HINGE, BATTERY |
| HLDR | HOLDER |
| HT-SINK | HEAT SINK |
| IB | INSTRUCTION BOOKLET |
| IDLE | IDLER |
| IND, L-R | INDICATOR, L-R |
| KEY, CONT | KEY, CONTROL |
| KEY, PRGM | KEY, PROGRAM |
| KNOB, SL | KNOB, SLIDE |
| LBL | LABEL |
| LID, BATT | LID, BATTERY |
| LID, CASS | LID, CASSETTE |
| LVR | LEVER |
| P-SP | P-SPRING |
| PANEL, CONT | PANEL, CONTROL |
| PANEL, FR | PANEL, FRONT |
| PRGM | PROGRAM |
| PULLY, LOAD MO | PULLY, LOAD MOTOR |
| RBN | RIBBON |
| S- | SPECIAL |
| SEG | SEGMENT |
| SH | SHEET |
| SHLD-SH | SHIELD-SHEET |
| SL | SLIDE |
| SP | SPRING |
| SP-SCREW | SPECIAL-SCREW |
| SPACER, BAT | SPACER, BATTERY |
| SPR | SPRING |
| SPR-P | P-SPRING |
| SPR-PC-PUSH | P-SPRING, C-PUSH |
| T-SP | T-SPRING |
| TERM | TERMINAL |
| TRIG | TRIGGER |
| TUN | TUNING |
| VOL | VOLUME |
| W | WASHER |
| WHL | WHEEL |
| WORM-WHL | WORM-WHEEL |

| サービス技術ニュース | |
|---|---|
| 番号 | 連絡内容 |
| G— — | |
| G— — | |
| G— — | |

アイワ株式会社
AIWA CO.,LTD.
Printed by: Schaltungsdienst Lange Berlin (Germany)
9420025, 912162
Tokyo Japan

〒110 東京都台東区池之端1—2—11 ☎03（3827）3111 （代表）